Materials

- Hardware Lengths

Hardware Lengths

If you need a piece of hardware to be calculated at a certain length you need to put the length into the "Extended Data 1" field.

